

## **GEAR OIL**



		Interval	
1st time	20 hours	1 month	*whichever comes first
From 2nd time	100 hours	1 year	

<sup>\*</sup>This guideline may vary by outboard motor model, condition of use, region, etc. Please refer to the owner's manual or ask an authorized Suzuki dealer for more information.

## **Purpose and Function**

For lubrication, anti-corrosion and cooling of pinion, forward gear and reverse gear in the lower unit which operates under high load and high revolutions.





## If overused without replacement ...

 Wear on moving parts, such as gear and bearing, progresses by pollution, degradation of oil, or circulation of oil containing metalled wear debris.

It is necessary to change gear oil periodically to new one so that original lubrication property can be performed.